






## Optional Accessories



### MOUNT



### SHAPING



### POWER



**i** To prevent damaging the lens, when lens mounted don't use a NP-F battery to power the light, but use an external power source through the DC connector.



# Quick Start Guide



**R300 SE**  
LED Ring Light

- 1 Getting Started
- 2 Functions



F&V Europe B.V.  
Steenovenweg 5, 5708HN Helmond, The Netherlands  
TM & © F&V All rights reserved.

For more information visit: [fvlight.com](http://fvlight.com)

## What's in the box?



## 1 Getting Started

### 1 Mounting



### 2 Power

Two power options

- 1 NP-F Li-ion battery
- 2 DC  $\Phi$ 2.5 10-18V


### 3 Let's do this!

Turn the light ON

- <I> when powering through DC Jack
- <II> when using NP-F batteries



## 2 Functions



### 1 Adjust the Intensity

Use <Intensity> knob to adjust the intensity

### 2 \* Adjust the Color Temperature (only the bi-color version)

Use <Color Temperature> knob to adjust the color temperature